

Short Range Systems



Operation

The ERL-10 receives data from the EFM-100 Electric Field Mill short-range sensor (<20 miles/32 km) and optionally also an LD-250 long range lightning detector. It constantly monitors for lightning and activates its timed relay outputs when lightning is detected. Up to three alarms can be configured, referred to as Red, Orange and Yellow Alert levels. The green All Clear state is entered when no lightning has been detected within the configured time period.

When the ERL-10 is first turned on it enters Survey Mode where it looks for lightning. After several minutes without lightning (configurable but typically 10-20 minutes) the system enters the All Clear state. The green All Clear light on the ERL-10 illuminates and the All Clear relay output activates.

Coincidence Mode

With Coincidence Mode enabled a lightning strike must be detected by both the EFM-100 and LD-250 for an alarm to activate. This dual sensor technology virtually eliminates false alarms that could be caused by persons, animals or birds coming too near the EFM-100 lightning sensor. Coincidence Mode is only applicable within the range of the EFM-100 (0-20 miles/32 km)

Status Monitor

The ERL-10 Status Monitor software (included) allows the system status and countdown timers to be displayed. Countdown timers clearly indicate the number of minutes:seconds until All Clear. All alarm activations are timestamped and logged to disk. Configuration software and graphical log-file viewing software is also included.

ERL-10 Lightning Relay Module

- ☑ 1, 2 or 3 alarms levels (Red, Red/Yellow, Red/Orange/Yellow)
- ☑ All Clear output (Green)
- ☑ Fully configurable alarm distances, durations and high electric field levels
- ☑ 20 miles/32 km range, optionally extendable to 40 miles/64km
- ☑ High electric field alarm warns of conditions where first strike is more likely to occur
- ☑ Coincidence Mode virtually eliminates false alarms
- ☑ Fault output indicates status of the system
- ☑ Status Monitor software shows current alarm state and minutes:seconds until All Clear
- ☑ USB port for configuration and/or Status Monitor software
- ☑ RS-485 output for transmitting status messages to other equipment and/or to a distant Status Monitor computer
- ☑ Optional fiber optic data connection between sensor and ERL-10 available



Stacklight connected to an ERL-10 (stacklight not provided) ERL-10 Status Monitor Software (included)

info@boltek.com

www.boltek.com

Tel. +1 (905) 734-8045

ERL-10 Lightning Relay Module

		Fachan	
Alarms	CIFICATIONS	Enclosure Material	Aluminum
Number of alert levels	1, 2 or 3 configurable	IP Rating	Aluminum 20
All levels configurable	Strike distance: 0 - 20 miles / 0 - 32 km	Dimensions	3.9" x 4.5" x 1.1" /
	(0 - 40 miles / 0 - 64 km with LD-250)	Dimensions	100 mm x 114mm x 28mm
	High electric field:	Environmental	
	-20 to +20 kV/m	Operating Temperature	-40 to 60 C / -40 to 140 F
LED Indicators		Operating Humidity	0 to 99% non-condensing
Power (green)	On when power applied	operating Harmany	o to oo w non condensing
EFM Data (green)	Flashes as EFM data is received	Agency Approvals	CE, FCC, cULus, C-tick
LD-250 Data (green)	Flashes as LD-250 data is received	Warranty	1 Year
Fault (red)	On when a sensor or module fault is	Ordering Information	
()	detected	ERL10-KIT1-120V-100FT	ERL-10/EFM-100 for 120VAC
Fault Code (red)	Blinks active fault codes	ERL10-KIT2-120V-100FT	ERL-10/EFM-100/LD-250 for 120VAC
All Clear (green)	On when no lightning has been	ERL10-KIT1-220V-100FT	ERL-10/EFM-100 for 220VAC
	detected	ERL10-KIT2-220V-100FT	ERL-10/EFM-100/LD-250 for 220VAC
Yellow Alert (yellow)	On when lightning is detected within the		
0 /	configured Yellow Alert range		ludes 100'/30m sensor cables.
Orange Alert (orange)	On when lightning is detected within the	Additional Cable	e lengths available on request.
	configured Orange Alert range	001115	
Red Alert (red)	On when lightning is detected within the	CONNECTION DIAGRAM (Fiber optic cable option also available)	
· /	configured Red Alert range		•
ault codes	-	,	Outdoor mounted lightning sensors
)	ERL-10 Processor Fault		
1	No EFM Data		
2	No LD-250 Data	EFI	M-100 ANT-2
3	EFM Rotor Fault		
4	EFM Selftest Fault (EFM-200 only)		
5	EFM Syntax Fault	I.	
6	EFM Checksum Fault		
7	EFM Unknown Fault		.
8	Watchdog Timer Reset		
9	Configuration Fault		
10	LD-250 Syntax Fault		
11	LD-250 Checksum Fault		
12	LD-250 Unknown Fault		
Software			
ERL-10 Configuration Software	Included		
ERL-10 Status Display Software	Included		
Operating System	Microsoft Windows 10, 8, 7, Vista, XP,	Cat6 cable	Cat6 cable (up to 60m/200ft)
	2000, NT	(up to 60m/200ft)	
Communications		Connect	
Configuration Port	USB	To Ground	
Status Data Port	USB, RS-485		
RS-485 Format	Delimited ASCII Sentences	EFA-21 power/	
	115,200 bps, 8N1	data module 12V DC power s	suppiy
EFM Data	RS-485 / Multimode ST fiber optic		l l
LD-250 Data	RS-232, 9600 bps 8N1	RS485 wire (up to 1200m/	T
Relay Outputs		(up to 1200m / 4000ft)	
Red Alert	Solid-state relay 80VDC/57VAC/2A		J
	configurable NO/NC	Optional	Status Monitor Display
Orange Alert	Solid-state relay 80VDC/57VAC/2A	Customer Equipment	(PC not provided)
	configurable NO/NC	DB	89 (RS232)
Yellow Alert	Solid-state relay 80VDC/57VAC/2A		Cable
	configurable NO/NC	ERL-10 Relay	
All Clear	Solid-state relay 80VDC/57VAC/2A	Module	
	configurable NO/NC		LD-250 long range
Fault	SPDT relay 250VAC/8A, 30VDC/5A	w T	detector (optional)
	with both NO/NC connections		USB Cable
Power			
Connector	2.1mm/5.5mm coaxial, screw terminals		ORY USE ONLY
Voltage	11.5VDC - 14VDC		
Power Consumption	4 W	This equipment does n	ot include self-test circuitry to
Source	120VAC US plug or 120-240VAC		onality. Additional measures
	international multi-plug wall adapter		
		should be in place to safe	eguard personnel or equipment
		· ·	

BOLTEK

info@boltek.com

www.boltek.com

Tel. +1 (905) 734-8045